Amber DT-two+ Thermostat

The DT-two+ is packed with all the features of the DT-two, with the addition of Wi-Fi connectivity and smart home integration.

Download the APP and control your underfloor heating even when away from home. Floor Sensor Length 3m.


08:00 Monday 20.0 Event Wake 20.0 Auto Mode: Event Wake ○ ★ ♥ ★ ▼

Features


- Wi-Fi Connectivity
- Smart Home Integration
- Large Colour Touch Screen Face
- 7 Day, 6 Period Programme
- Floor Temperature Limiting Function
- Sensor Offset
- Frost Protection
- Holiday Mode
- 2 Year Warranty

Technical Specifications	
Supply Voltage	85-265Vac 50/60Hz
Standby Power Consumption	< 1W
Max Load	16 Amp
IP Class	IP21
Cable Specification	2.5mm2
Housing Material	Anti-flammable PC

Wiring Diagram







Step 2: Connect the thermostat according to the Wiring Instruction.





Step 3: Insert the back panel into wall box with provided screws.

Step 4: Align top part of front panel and back panel to fit these two parts. Then fix them with screw.



